



Klip Gait Trainer

User Manual

Item #s

Four-wheeled Klip Gait Trainer

KP410, KP420R, KP430, KP440B

Four-wheeled Klip Gait Trainer with Seat

KP510, KP520R, KP530, KP540B

Four-wheeled Klip Gait Trainer with 8" wheels

KP418, KP428R, KP438, KP448B

**Four-wheeled Klip Gait Trainer with 8" wheels and
Seat KP518, KP528R, KP538, KP548B**

Obelis S.A.
Bd. Général Wahis 53
B-1030 Brussels, Belgium
Max User Mass 38.5 kg/85 lbs.



www.circlespecialty.com

INTRODUCTION

Thank you for purchasing the Klip Gait Trainer!

To safely operate and maintain your walker properly, please read this User Manual carefully before using and save it for future reference. Taking proper care of your walker will ensure longevity and that you fully benefit from its features.



GENERAL USE

UNFOLD GAIT TRAINER: Grasp front and rear legs and pull away from each other. Continue to unfold the frame until the latch push pins snap into place and fully protrude from the hole.

ASSEMBLY: Match numbered markings on leg with frame, press in the pushpins and slide into the leg frame.

HEIGHT ADJUSTMENT: To determine the correct height for the gait trainer, the length measured from the crease of wrist-to-floor should be the handle height.

adjust height, press the push pin on each leg and slide the leg to the proper position. Always check that all 4 legs are the same height and that the push pins fully protrude from the holes.

LOCK/UNLOCK SWIVEL WHEELS: Press down on the green lever to lock wheel and lift to unlock. Make sure that wheel clicks into place when locking the wheel.

NOTE: This feature is not available on models with 8" wheels.

ONE-DIRECTIONAL REAR WHEELS: To disengage directional lock, raise aluminum pin and place into override bracket.

ANTERIOR/POSTERIOR SETUP: Front and rear legs can be interchanged to switch from posterior to anterior use for all gait trainers other than (KP210R) KP410,

KP 510, KP418, KP518.

FOLD GAIT TRAINER: Face walker from the open end, raise front wheels so that walker is resting on rear wheels/legs, press in latch push pins and push front legs towards rear legs.

SEAT: Flip up seat when standing and walking. Fold down seat for sitting and resting. When folding gait trainer, seat must be raised

MAINTENANCE AND CARE

Inspect your gait trainer by checking all screws, nuts and bolts regularly.

Keep your walker clean to ensure longevity and comfort while using it. Mix warm water with a mild detergent and gently scrub your walker. Wipe clean with a dry soft cloth.



3 YEAR LIMITED WARRANTY

This warranty is solely for the benefit of the original consumer purchaser and is in effect from date of purchase.

Circle Specialty Inc. warrants that the Klip gait trainer frame will be free from defect for a period of three (3) years.

The warranty does not extend to non-durable components; such as, rubber accessories and grips.

This warranty does not cover device failure due to owner misuse or negligence. It only applies when product is used according to the specified conditions and for the intended purposes.

If within the warranty period any such product shall be proved defective, such product will be repaired or replaced at Circle Specialty's option.

If you have a question about your Circle Specialty gait trainer or this warranty, please contact an authorized dealer.



Circle Specialty, Inc.

Brooklyn, NY 11232, USA

718.943.6452

info@circlespecialty.com

2020/Rev 3-20