

Buckle Guard/Retainer Clip Guard

User Manual

Item #

BKLEGRD



Thank you for purchasing your Buckle Guard/Retainers Clip Guard

To ensure safe use and maintenance, please read this User manual carefully before using and save it for future reference. It has been manufactured to high quality standards to provide reliable, long-term use. The Buckle Guard/Retainer Clip Guard are tamper-resistant covers designed to help prevent children from pressing the release button on seat belts or release clips.

SAFETY

The Buckle Guard/Retainer Clip Guard may deter many children, but no device can be effective in all situations.

Always closely supervise your child to ensure they cannot undo the Buckle Guard/Retainer Clip Guard. If your child is able to unbuckle or exit the stroller while the Guard is in use, seek alternative restraint solutions.

Be aware that using either or both guards may increase the time required to remove your child, which could be critical in an emergency. Teach all family members and caregivers how to quickly open both Guards.

GENERAL USE

The Guards conceal the release button beneath a child-resistant safety cap, making it difficult for curious or confused children to unbuckle themselves. When properly installed and used, the Guard/s ensure that children remain securely fastened.

INSTALLATION

1. Open the Buckle Guard/Retainer Clip Guard by pushing down and twisting the white cap counterclockwise.
2. Once the cap is removed, open the Guard along the hinged back. Note that there are two slots – the top slot is narrower and the bottom is wider.



FOR BUCKLE GUARD

Place the Buckle Guard over the seat belt buckle button with the narrow slot is at the top. The crotch strap comes out through the wide slot at the bottom.



FOR RETAINER CLIP GUARD

Place the Retainer Clip Guard over the retainer clip with the narrow slot positioned at the top.

To release the Buckle Guard/Retainer Clip Guard, push down and twist the white cap counterclockwise at the same time to remove it and access the release button. Press the button and open the buckle as usual.

TWO YEAR LIMITED WARRANTY

This warranty is solely for the benefit of the original consumer purchaser and is in effect from date of purchase.

Circle Specialty Inc. warrants that the Buckles will be free from defects for a period of two years.

The warranty does not extend to non-durable components, any components that are subject to standard wear and tear and damage caused by misuse, abuse or negligence.

It only applies when the product is used according to the specified conditions and intended purposes

If a defect is found during the warranty period, Circle Specialty, at its discretion, will repair or replace the product.

If you have a question regarding this product or warranty, please contact an authorized Circle Specialty dealer.